

HINT: As you approach the source of the leak, continue pressing the "B" button to slow down the tick if it is rapidly increasing. If the tick is no longer heard press the "B" button to reset. Pressing the "A" button deactivates the tick.

IMPORTANT: When replacing the gooseneck into the clip on the right side, wrap the gooseneck in a wide circular manner counter-clockwise around the back of the instrument. Bending in the opposite direction may cause damage over the life of the product.

WARNINGS:

To prevent ignition of flammable or combustible atmospheres, disconnect power before servicing.

To reduce the risk of ignition of a flammable atmosphere, batteries must only be changed in an area known to be nonflammable.

Do not mix batteries of different age or type.

Not for use in atmospheres of oxygen greater than 21%.

ONLY zero instrument in a gas free environment.

To maintain intrinsic safety, service must be performed by factory authorized technicians with approved replacement parts only.

MADE IN USA



851 Transport Drive
Valparaiso, IN 46383-8432

Phone: 219 465 2700
Web: www.gasleaksensors.com

Innovative Detection Solutions

SENSIT® CO

SENSIT® GOLD

SENSIT® GOLD 100

SENSIT® GOLD CGI

SENSIT® GOLD G2

SENSIT® HCN

SENSIT® HXG-2

SENSIT® HXG-2d (2dr)

SENSIT® HXG-3 (3P)

SENSIT® P100

SENSIT® P400

SENSIT® PMD

SENSIT® RLD-2

SENSIT® TKX

TRAK-IT® IIIa

ULTRA-TRAC® MJL

GAS-TRAC®

EX 1000

SMART-CAL™

SCAL-100

SCAL-N™

Distributed by:

Quick-Start Instructions



This is not a substitute for the instruction manual. It is for reference only.

Read and understand the instruction manual before use.

SENSIT® GOLD G2

QUICK-START INSTRUCTIONS

1. Install the batteries by removing the retaining screw (torx) from the handle. Push down the locking tab and slide the handle away from the top of the instrument. When replacing handle be sure the tab is securely in place and replace the retaining screw.

2. **IMPORTANT:** CAREFULLY OBSERVE POLARITY WHEN CHANGING BATTERIES. Instrument will not function with improperly installed batteries.

3. Locate button "A" – push & hold until the unit powers up, then release the power button.

4. Allow unit to go through the warm up sequence in clean air. At the end of warm up, the unit will auto zero and enter the working display. This requires from 40 up to 180 seconds.

5. If **FAIL** is displayed for any of the sensor readings, make sure the instrument is in clean air; push and hold the "C" button until AUTO ZERO is displayed. If this process does not clear the fail on the display, this could indicate a problem with the instrument or sensor.

6. Look at the display – Up to four (4) gases are shown: O2, LEL, H2S (or HCN) and CO.

7. The combustible gas scale will automatically range from %LEL to %Volume if so equipped with the 100%v/v (TC) sensor.

8. Extend the goose neck (the LEL sensor and filter cap is at the tip).



9. Place your finger over the inlet and wait ~5 seconds for "FLOW BLOCKED" to appear on the display. Change cap and "O" rings if it does not show "FLOW BLOCKED".

10. You are now ready to use the instrument. You can now enter the area and detect gases.

11. Once the environment is determined to be safe to work in, if the source of an odor needs to be located, press and release the "B" button. If needed use the "C" button to find "TICK" menu function. Press the "B" to hear a tick rate. Once an investigation is begun, as the instrument is moved closer to a combustible source, the tick rate will increase. Press the "B" button again to reset the tick to for a slower tick. "A" button deactivate the ticking sound.

12. Any "NSC" readings indicate a combustible gas sensed other than the one the instrument is calibrated to measure.

Any "NSR" readings indicate a non-combustible gas sensed the instrument is not calibrated to measure. (found on instruments with 100%v/v (TC) scale only)

13. Press and hold the "C" button to zero the instrument. (only in a gas free area).

14. When your investigation is complete, push button "A" and hold for 5 seconds until the instrument displays "POWER OFF" then release to shut off.

Stand Alarms:

Low:	5% LEL
Hazard 1:	10% LEL
Hazard 2:	25% LEL
Hazard 3:	50% LEL
Oxygen:	Below 19.5%, Above 23.5%
CO:	35 PPM
H2S:	10 PPM